



Fitting the basin to the unit

- 11** Firstly decide which side you would prefer your tap to be situated on the cabinet and turn the basin accordingly to suit your preferred preference. Bed the basin to the top of the cabinet on a bead of silicone sealant as shown and allow to fully cure. This will hold the basin securely in place when fully cured.



- 12** You may also wish to seal where the cabinet and basin meet the wall with a neat smooth bead of sealant as shown below.



PRODUCT AFTERCARE

We recommend cleaning with a soft damp cloth and mild soap solution.
Do not use cream cleaners or cleaners containing bleach
Do not scrub or scour
Do not use abrasive cleaning agents
Do not use solvent based cleaners
If a polish is to be used, use a wax free polish
Do not allow pools of water to remain standing on the surfaces


IMPORTANT

We recommend that you read the sealant packaging for the curing time. Do not use the unit until the sealant is set. Please consult with an expert if you are unsure. We recommend that a qualified trades person is used for all plumbing work.
If you are unsure of any part of the instructions shown in this booklet we recommend that you contact a reputable qualified trades person.

Compact Wall Hung Cabinets

W30/216


Wall Hung Compact Cabinet




Fittings Supplied

- A** 1 x LH Wall Cabinet Hanger & Cover
1 x RH Wall Cabinet Hanger & Cover

- B** 2 x Wall Fixing Plates
(Fixings not supplied)



Floor Compact Cabinet




Fittings Supplied

- A** 2 x Wall Brackets

Wall cabinet hangers are not supplied with this unit.

- 1** Remove the wall cabinet hangers (A) from the packaging and fit them to the correct corresponding sides of the cabinet. The cabinet hangers are fitted to the sides of the cabinet by using a cross headed screwdriver and the fixing screws supplied with the cabinet hangers as shown below.




LH Wall cabinet hanger shown

Before you start, read instructions carefully.

Check the pack and make sure all the components are included. When you are ready to start make sure you have the right tools to hand and a clean dry area to work in.

CLEANING: Use a mild soap and water only. Do not use abrasive cleaners. See aftercare instructions.


- 2** Using a tape measure, measure the internal distance from the back of the unit to establish the distance between the wall fixing plates (B) and replicate this position onto the wall using a pencil at the required height you intend your cabinet and basin to finish at.




- 3** After marking out, fix the wall fixing plates onto the wall using the correct type of wall fixings to suit the type of wall you are fixing to. Please note wall fixings are not supplied as wall types may vary. If you are fixing onto dry boarded constructed type wall, you will need to ensure that the fixings can be securely held in place by some kind of solid framework etc. If you are at all unsure please contact a reputable trades person for professional advice.

NOTE:- It is good practice to fit all pipework and plumbing before fixing the units to the wall to enable easier installation and fitting.


- 4** To secure the cabinet to the wall this is achieved by using a cross head screwdriver and turning the bottom screw as shown clockwise until the cabinet is secured in place.




- 5** For vertical adjustment this can be achieved by using a cross headed screwdriver and turning the top screw as shown either clockwise or anti clockwise to level the cabinet.




- 6** To fit the handle, remove the door from the cabinet simply unclip the hinges from the base plate by pushing the clip at the rear on the arm of the hinge as shown below. This will release the hinge from the hinge base plate.



- 7** When fitting the handle, firstly decide if you are having the handle horizontal or vertical on the unit. Place the door face down onto a piece of scrapboard and carefully mark out the handle positions by measuring the centres of the handle and replicating them onto the door. Make sure that the handle bolts will not foul on the carcass. Drill the door in the required positions. **IMPORTANT:-** make sure that you have correctly identified the drilling position before commencing with any drilling to prevent any mistakes from occurring.




- 8** To re-attach the door to the cabinet, simply offer the door back to the cabinet and align the hinges to the hinge base plates. Using gentle pressure push the arm of the hinge onto the hinge base plate until it locks into position. Do not let go of the door until you are certain that the door is securely held in place.




- 9** The hinges can be adjusted by following the instructions below, therefore allowing you to align the door with the unit.


To adjust the door in and out on the unit, loosen the screw as illustrated on both of the hinges and move the door to the required position.



To adjust the door up and down on the unit, loosen both screws as shown on both hinges and move the door to the required position. Retighten all screws after.



To adjust the door left and right on the unit, turn the screw as illustrated on both hinges.



- 10** If your door has a protective film applied to it, now is the time to remove it by gently peeling it away. Fit the handle to the door by simply screwing into place using a cross headed screwdriver and 2 x handle bolts (D) provided. Take care not to over tighten.

